

INSTALLATION PRECAUTIONS

Choose the mounting location carefully, observing the following

- The unit is not subject to temperatures exceeding 55 C
(Such as in a car parked in direct sunlight)
- The unit is not subject to direct sunlight.
- The unit is not near heat sources (such as heaters).
- The unit is not exposed to rain or moisture.
- The unit is not exposed to excessive dust or dirt.
- The unit is not subject to excessive vibration.

TROUBLE SHOOTING GUIDE

(1) *The display does not show the radio information.*

- Reset the head unit using the recessed front panel button (see user manual)
- Check the uni-link plug is fitted to the rear socket of the head unit.
- Check the 14pin plug is installed into the adapter.
- Check the connections to the adapter and head unit.
- Check that the connection to the head unit remote power has been made (Step 5)
- Consult your supplying dealer.

(2) *The steering wheel controls do not operate the head unit.*

- Reset the head unit using the recessed front panel button (see user manual)
- Check that the 3.5mm jack plug is fitted into the 3.5mm socket of the head unit.
- Check the correct fitting of the 14pin plug to the adapter.
- Check for broken or loose wiring within the supplied harness.
- Consult your supplying dealer.

(3) *The head unit does not operate after installation.*

- Reset the head unit using the recessed front panel button (see user manual)
- Check all connections are pushed fully into the rear terminal block on the car head unit.
- Check that there are no broken pins on the lead or rear terminal.
- Check the supply fuse to the head unit.
- Consult your supplying dealer.

WARRANTY

- This product is covered by a 12month warranty valid from the date of purchase
- The adapter and lead will be replaced free of charge if failure is due to a manufacturing defect.
- The adapter must have been fitted as per the installation instructions.
- The unit must be returned to your supplier for any claim under the terms of this warranty.
- This does not affect your statutory rights.

INSTRUCTIONS



**Fitting instructions for
DPGS001, DPGS002
& DPGS003
PEUGEOT
DISPLAY DRIVER
AND STALK ADAPTER**

**Please read these instructions fully before you commence.
For information on your Sony product please consult the
instruction booklet supplied with it.**

Part1: Removal of existing equipment.

STEP 1

Before installation be sure to turn the ignition off.

STEP 2

Remove the original car head unit as per the manufacturers instructions.
Note that some car head units are code protected and you are advised to know what this code is before you remove it.

STEP 3

Disconnect all wiring looms from the rear of the head unit.

Part2: Installation of the Sony head unit and display adapter.




STEP 1

Plug the 14 pin connector of the supplied loom into the adapter.

STEP 2

Plug the unilink connector and 3.5mm jack plug from the supplied loom into the back of the Sony head unit. Ensure the arrow is at the top of the unilink connector and that the 3.5mm jack plug is pushed firmly into the Sony head unit.



STEP 3

Insert the original power and speaker leads from the vehicle into the Connects2 harness.

STEP 4

Connect the Sony head unit to the unused end of the supplied harness.

STEP 5

If also fitting an auto-changer, connect the unilink bus cable supplied with the auto-changer to the unilink socket on the adapter. Connect the audio leads from the auto-changer to the Sony head unit as normal. (See fitting instructions with autochanger for further information).

STEP 6

Place the adapter and loom into the space behind the head unit, taking care not to trap any wires.

STEP 7

Install the Sony head unit as shown in the manufacturers instruction manual.

STEP 8

When you have secured the Sony head unit into the car, press the reset button on the front of the head unit before turning the unit on. (Please consult your head unit instruction book). **Failure to complete this step may result in the adapter not functioning correctly.**